

Concelo®

INSTALLATION INSTRUCTIONS FOR:

CRL350-135D / CRL450-235D

CRL450-160D

LAUNDRY



READ ALL INSTRUCTIONS BEFORE INSTALLING THIS BIN UNIT.
FAILURE TO INSTALL THE BIN CORRECTLY MAY VOID WARRANTY.

INSTALLATION VIDEO PLEASE WATCH FIRST:

NZ: hideawaybins.co.nz/concelo-laundry-installation
AUS: hideawaybins.com.au/concelo-laundry-installation
Or scan the QR code...

If predrilling using CNC refer to:

NZ: hideawaybins.co.nz/info/downloads
AUS: hideawaybins.com.au/info/downloads
for drilling position CAD files.

New Zealand



Australia



BENCH OVERHANG CLEARANCE:

The Hideaway Concelo Laundry range has been designed with over extension drawer runners which allow for a certain bench overhang. CRL450-160D models allow up to 50mm clearance, while CRL450-235D models allow up to 40mm clearance and 110mm on the CRL350-135D. If more bench overhang clearance is required, please mount the bin lower in the cabinet.

HIDEAWAY NEW ZEALAND

09 426 7456 / info@hideawaybins.co.nz / hideawaybins.co.nz

HIDEAWAY AUSTRALIA

1800 042 642 / info@hideawaybins.co.nz / hideawaybins.com.au



May 2022

Step 1 – Unpack carton

- The hamper and associated parts should be put to one side.
- Inner Carton 1 contains collar components to be attached to the door panel.
- Inner Carton 2 contains runners and mounting brackets to be mounted to the cabinet carcass.

Step 2 – Mount collar to door panel

- Open Inner Carton 1 and follow the Concelo Laundry Collar Installation Instructions within.


Step 3 – Mount runners inside cabinet carcass

- Open Inner Carton 2 and follow the Concelo Laundry Runner Installation Instructions within.

Step 4 – Assemble collar and door panel to runners

- Position collar assembly as shown in Fig 4. **TIP:** Ensure that runners are pulled forward, there is a black tab at the front of the runner that can be pulled while holding the door panel.

FIG.4




- Lower the door panel until a click is heard. **TIP:** The door panel will need to be pushed down firmly.
- Close the product and check that it is approximately level. **TIP:** If the door panel is significantly out of level it may indicate that it is not clipped down fully on one side.

Step 5 – Adjust the door panel position (Fig 5)


- Loosen the 6 door bracket bolts using the 4mm Allen key provided.
- Adjust the door to be square and parallel to carcass and in the correct vertical position using the adjustment cams.
- Tighten the 6 door bracket bolts.
- Loosen the 6 door mounting screws and adjust the horizontal position of the door panel.
- Tighten the 6 door mounting screws.

FIG.5




Step 6 – Fit the door bracket covers (Fig 6)

FIG.6



Step 7 – Install internal tray(s), hamper(s) and trims (35L models only) (Fig 7)

FIG.7



TOP

CARCASE FRONT LEFT



← **DRILL:** Ø 5 x 13mm deep

CRL450

CRL350



CRL450

CRL350

CRL450

CRL350



NOTE: If the unit is to be positioned higher in the carcass, trim the required amount off the top of the template.
Cannot exceed:
CRL450-160D = 40mm
CRL350-135D = 65mm
CRL450-235D = 65mm

This must be done before proceeding with Step 2 Collar Installation and the change will apply to both Collar and Runner Installation.

← **DRILL:** Ø 2 x 5mm deep

DOOR CENTRE

CRL350

CRL350

CRL350



CRL450

CRL450

CRL450



CRL450

CRL450



CARCASE FRONT RIGHT