

Concelo.®


BY HIDEAWAY

INSTALLATION INSTRUCTIONS FOR: *LAUNDRY RUNNER*

CRL350-135D / CRL450-235D / CRL450-160D

READ ALL INSTRUCTIONS BEFORE INSTALLING THIS BIN UNIT. FAILURE TO INSTALL THE BIN CORRECTLY MAY VOID WARRANTY.

CONTENTS OF CARTON TWO:



Runner Installation

TIP: For new kitchens, where possible, it is easiest to place the carcass on a bench for installation of the runners.

Step 1 - For each runner align the template with the top and front edge of the carcass.

Step 2 - On each side mark the 4 side mount (GREEN) holes through the template.


Step 3 - Remove the template and drill 5mm holes 13mm deep at each location.

Step 4 - Secure runners using the 13mm Euro screws provided.

NOTE: If the unit is to be positioned higher in the cabinet trim the required amount off the top of the template. Trimming the template will adjust the mounting hole positions for both the collar and runner installation so they remain correctly aligned.

The maximum amount that can be trimmed off is up to:

CRL450-160D = 40mm / CRL350-135D = 65mm / CRL450-235D = 65mm



NOTE: Cabinet shown lying on left side.

HIDEAWAY NEW ZEALAND 09 426 7456
info@hideawaybins.co.nz / hideawaybins.co.nz

HIDEAWAY AUSTRALIA 1800 042 642
info@hideawaybins.co.nz / hideawaybins.com.au


Hideaway®

MEMBERS AND SUPPORTERS OF

NKBA™
National Kitchen & Bathroom Association - NZ


NEW ZEALAND
MADE®

May 2022