


Concelo®

BY HIDEAWAY

INSTALLATION INSTRUCTIONS FOR: LAUNDRY COLLAR CRL350-135D / CRL450-235D CRL450-160D

READ ALL INSTRUCTIONS BEFORE INSTALLING THIS BIN UNIT. FAILURE TO INSTALL THE BIN CORRECTLY MAY VOID WARRANTY.

CONTENTS OF CARTON ONE:



Step 1 – Marking door panel for template (Fig 1/2)

- Mark a vertical centre line on the rear of the door panel (a).
- Mark a horizontal line indicating the inside top edge of the carcass for door overlap (b).

TIP: An allowance needs to be made for the door overlap with the top of the carcass e.g. for a 16mm thick carcass material and 3mm gap between the door panel and the bench top the horizontal line should be (16-3) = 13mm down from the top edge of the door panel (b).

NOTE: If the unit is to be positioned higher in the cabinet trim the required amount off the top of the template. Trimming the template will adjust the mounting hole positions for both the collar and runner installation so they remain correctly aligned.

The maximum amount that can be trimmed off is up to:

CRL450-160D = 40mm / CRL350-135D = 65mm / CRL450-235D = 65mm

Step 2 – Pre-drill door panel (Fig 2)

- Align the door panel template with the lines as indicated and mark the 6 mount holes (CRL450 models RED / CRL350 model BLUE) through the template.
- Drill a 2mm pilot hole at each of the 6 mounting locations.

TIP FOR FRAMED DOORS: 3 screw locations are required for each door bracket. An alternative location for the top screw is accessible by removing the door bracket from the collar side. This should be used in framed door situations and should be inserted after step 5 of the Installation Instructions. Refer overleaf for instructions.

Step 3 – Install collar side sub-assemblies

Refer to Fig. 3

3.1 - Position collar side assemblies.

3.2 - Secure each using 12mm Surefix screws provided.

Step 4 – Install collar rear panel on to collar sides

Refer to Fig. 3

4.1 - Position collar rear panel as shown.

4.2 - Secure using 6g x 12mm self-tapping screws.

NOTE: do not use impact driver or high torque setting.

FIG.1




FIG.2






FIG.3




Addendum - Third screw location for framed doors

- Complete Step 5 (Adjust the door panel position) of the Concelo Laundry Installation Instructions.
- Follow the steps below to remove the door panel and add the third screw.


1. Remove the 6 door bracket bolts using the 4mm Allen key provided.



2. Tilt the door panel forward till the door bracket is clear of the top adjustment cam.



3. Lift the door panel clear of the lower adjustment cam.



4. Drill a 2mm pilot hole at the top mounting location of each door bracket. Insert 12mm Surefix screws provided and tighten.

5. Reassemble door bracket to collar and secure in place using 6 door bracket bolts.

- Once complete, refer back to Step 6 and Step 7 of the Concelo Laundry Installation Instructions to complete installation.

HIDEAWAY NEW ZEALAND 09 426 7456
info@hideawaybins.co.nz / hideawaybins.co.nz

HIDEAWAY AUSTRALIA 1800 042 642
info@hideawaybins.co.nz / hideawaybins.com.au



MEMBERS AND SUPPORTERS OF

